

e-medical™ Silence ST-M bracket



Accessories for e-medical™ Silence ST-M(i) and ST-M(b)

**Combined bracket to mount your fanless e-medical™ Silence
ST-M(i) or ST-M(b) to:**

- Rail mount
- VESA (100x100 mm)
- wall / back plate



VESA-Mount



1. Attach the supplied screws to the four VESA mounting points of the monitor or support arm.



2. Mount the supplied VESA mounting plates on the PC. Remove the device feet for this if necessary.



3. Hook the heads of the four screws into the holes of the VESA mounting points. Slide the device down to secure it.

Mounting the device feet



1. Fit the rubber feet with the screws.



2. Mount the rubber feet on the device.